

PowerView® Motorisering

Smarta gardiner som gör livet lite enklare

Hissgardiner

Kontrollera att dina gardiner är korrekt monterade och att de är kopplade till batterirör eller transformator.

BETJÄNING

Välj en eller flera kanaler, eller ALL (alla) samtidigt.
Den valda kanalen kommer att lysa.

- Tryck på ▼ CLOSE för att sänka hissgardinen.
- Tryck på ▲ OPEN för att höja hissgardinen.
- Tryck på ■ STOPP för att ställa hissgardinen i en specifik position.

Tryck på ♥ FAVORIT för att placera hissgardinen i din förinställda favoritposition.
Se Quickstart guide för inställning av favoritposition.

BETJÄNING UTAN FJÄRRKONTROLL

- Vill du sänka hissgardinen, tryck in och håll kvar hissgardiner programmeringsknapp i 3 sekunder.
- Stanna hissgardinen genom att trycka på programmeringsknappen igen.
- Höj gardinen genom att trycka in och håll kvar hissgardiner programmeringsknapp i 3 sekunder.



Programmeringsknapp



www.luxaflex.se/powerview-installation

All rights reserved. Unauthorised copying is prohibited. Technical data subject to change without notice. No rights can be derived from copy, text pertaining to illustrations or samples. Subject to changes in materials, parts, compositions, designs, versions, colours etc., even without notice. * Registered trademark. A HunterDouglas® product. © Copyright HunterDouglas® 2016.